

# IMPORTANT ANNOUNCEMENT

To: Wilbert Licensee Network  
From: Broadview's Engineering Department  
Re: Announcing Reformulated Unidex® II Adhesive  
Date: February 1, 2019

Over the past several months, Wilbert Funeral Services, Inc. (WFSI) has been testing a new formulation of Unidex® Plus without the primer. The sole purpose of the primer was to etch ABS plastic thus allowing the adhesive to stick to the ABS liner. Since we no longer utilize ABS plastic in our liners, the primer was an unnecessary ingredient.

The new reformulated adhesive is named Unidex II and will replace both the Unidex Plus and the TK adhesive. The mixing procedure, application process and vent time for Unidex II remains the same as Unidex Plus and the TK adhesive. It is important to measure equal quantities of Part A and Part B and mix thoroughly. Apply 22 to 24 oz. of Unidex II to a base liner, and 10 to 12 oz. of Unidex II to a cover liner. You will notice that Unidex II rolls easier on the liner than Unidex Plus.

We changed the colors of Part A and Part B to avoid confusion with the current Unidex Plus and the TK adhesive. Unidex II Part A is white, and Part B is blue; when mixed together they produce a light blue color. Each drum contains a label identifying it as Part A or Part B, and the top of the drums are painted white or blue. Pails of Part A and B are also color coordinated to match the components.

Part A or B of Unidex II **cannot** be mixed with your inventory of Unidex Plus or TK adhesive. If you need to balance your existing quantity of Part A or B, we have a limited supply of Unidex Plus and the TK adhesive. Make sure to tell Inside Sales if you are balancing your current supply, so we send you the correct product.

Effective Monday, February 4<sup>th</sup>, all new adhesive orders will be earmarked to receive Unidex II. Orders that were already in-house prior to February 4<sup>th</sup> will receive Unidex Plus or TK adhesive as you specified at the time of the order.

The new stock codes for Unidex II are:  
E51P-U2 Unidex II Part A (Pail)  
E52P-U2 Unidex II Part B (Pail)  
E511P-U2 Unidex II Part A (Drum)  
E512P-U2 Unidex II Part B (Drum)